09/2018

# Mod: E50NC/R2

**Production code: UFFS1450GCP-P** 



# **Model:**

# UFF370G, UFF370SD, UFSC370G, UFSC370SD UFFS1450GCP, UFSC1450GCP



# **UK** Contents

Important safety instructions	13
Unpacking and installation	13
<b>Electrical connection</b>	13
Start-up of the cabinet	13
Control panel	14
Defrosting	14
Lock	15
Maintenance and cleaning	15
Service	15
Disposal	16

112-070920



### **Important safety instructions**

- 1. To obtain full use of the cabinet, we recommend reading this instruction manual.
- 2. It is the user's responsibility to operate the appliance in accordance with the instructions given.
- 3. Contact your dealer immediately in case of any malfunctions.
- 4. Place the cabinet in a dry and ventilated place.
- 5. Keep the cabinet away from strongly heat-emitting sources and do not expose it to direct sunlight.
- 6. Always keep in mind that all electrical devices are sources of potential danger.
- 7. Do not store inflammable material such as thinner, gasoline etc. in the cabinet.
- 8. We declare that no asbestos nor any CFC are used in the construction.
- 9. The oil in the compressor does not contain PCB.

## **Unpacking and installation**

Remove the wooden pallet and the packing. External surfaces are supplied with a protection foil, which must be removed before installation

# **Electrical connecting**

The cabinet operates on 230 V/50 Hz.

The wall socket should be easily accessible.

All earthing requirements stipulated by the local electricity authorities must be observed. The cabinet plug and wall socket should then give correct earthing. If in doubt, contact your local supplier or authorized electrician.

The flexible cord fitted to this appliance has three cores for use with a 3-pin 13-Amp or 3-pin 15-Amp plug. If a B.S. 1363 (13-Amp) fused plug is used, it should be fitted with a 13-Amp fuse.

The wires in this mains lead are coloured in accordance with the following code: Green/Yellow: Earth, Blue: Neutral, Brown: Live.

The main electrical connections must be done by skilled electricians.


## **Start-up of the cabinet**

Before use, we recommend that the cabinet is cleaned, see the section on maintenance and cleaning.

#### **Important!**

If the cabinet has been vertically placed during transport, please wait 2 hours before starting up the cabinet.

# **Control panel**



The thermostat can be positioned from app. -15 to -25°C.

A positioning in app. the middle of the scale will in must cases be ideal.

The cooling system can be disconnected at a positioning at 0.

The green lamp must always light up when connecting the cabinet.

Models with glass door are equipped with a switch for internal light.

Thermometer that shows the temperature of the freezer.

Door switch, which disconnects the internal fan when the door is opened.

# **Defrosting**


We recommend defrosting the freezer every three month or if the layer of ice exceeds 5 mm.

Do never use metal or other sharp objects to scrape the shelves as it can damage the freezer

- 1. Disconnect the freezer
- 2. Empty the freezer
- 3. Leave the freezer with the door open
- 4. Use the plastic scraper to remove the ice from the inner liner
- 5. Remove the drain plug and open the drain on the front side of the freezer and place a tray under the drain
- 6. Clean the freezer with mild detergent and wipe thoroughly
- 7. Connect the freezer and it is ready for use.

#### Lock

The freezer is supplied with a lock in the door



# Maintenance and cleaning

Switch the freezer off at the socket.

The cabinet must be periodically cleaned. Clean the external and internal surfaces of the cabinet with a light soap solution and subsequently wipe dry.

Do NOT use cleansers containing chlorine or other harsh cleansers, as these can damage the surfaces and the internal cooling system.

Clean the condenser and the compressor compartment using a vacuum cleaner and a stiff brush.

Do NOT hose the compressor compartment with water as this can cause short circuits and damage on the electrical parts.

#### Service

The cooling system is a hermetically sealed system and does not require supervision, only cleaning.

If the cabinet fails to cool, check if the reason is a power cut.

If you cannot locate the reason to the failure of the cabinet, please contact your supplier. Please inform model and serial number of the cabinet. You can find this information on the rating label which is placed inside the cabinet in the top right hand side.

# Disposal

Disposal of the cabinet must take place in an environmentally correct way. Please note existing regulation on disposal. There may be special requirements and conditions which must be observed.

